

ExpressCube™ SizeIt™ Software



The ExpressCube SizeIt software is a computer application that is loaded into a local computer to permit the user to control and collect data from the ExpressCube countertop unit via a USB interface cable.

The ExpressCube SizeIt software is not required if either an LCD Control module or a third party software is used to operate the ExpressCube countertop unit.

Minimum Computer Requirements

- Minimum 512 meg of available RAM
- Pentium IV or better @ 2.0 GHz or better
- Windows XP operating system
- CD-ROM drive
- Java version 1.5.0_06 or later